



INSTALLATION INSTRUCTIONS

GE3BPB1—GE3 Three Sided Backing Plate For GE3 Electric Fireplace Insert

NOT FOR USE WITH GAS MODEL FIREPLACES



GE3BPB1 3-Sided Backing Plate shown with
GE3CFV Clearview Front




Installation—GE3CFV Clearview Front

With Magnets. If the front has magnets at the top, install it by snapping it to the backing plate.

With Hanging Brackets. If the front is supplied with hooks and hanging brackets (supplied loose), secure the hanging brackets to the top interior corners of the backing plate with 2 screws each. Matching hook brackets are already installed on the front.


Hanging bracket detail




GUIDE D'INSTALLATION

GE3BPB1—GE3 Plaque de finition à 3 côtés pour foyer électrique GE3

NE PAS UTILISER AVEC LES FOYERS À GAZ



GE3BPB1 Plaque de finition à 3 côtés montrée avec
GE3CFV Devanture Clearview



Installation—Devanture Clearview GE3CFV

Avec aimants. Si la devanture n'a que des aimants, installez-la en la posant centrée sur la plaque de finition.

Avec supports d'accrochage. Si la devanture est fournie avec des supports d'accrochage, fixez-les aux coins intérieurs de la plaque de finition avec deux vis fournies. Les crochets sont déjà installés sur la devanture.

